

Pure RainTM
STORMWATER TREATMENT

FILTER SOCKS

Installation & Maintenance

Stormwater
BIOCHAR.COM

STORMWATER
TREATMENT



Regardless of installation, the Filter Sock should always be installed with the media as evenly distributed as possible, short and wide is best.

When installing around a Catch Basin, Filter Socks should be installed all the way around the grate. Allow six to eight inches if possible from the grate to the inside edge of the Filter Sock.

For Surface Runoff, Filter Socks should be installed in the pathway in a chevron to slow the water, giving maximum contact time for best results.



*Filter Socks may give off a dust or fines from filling, transportation, installation and maintenance. This is normal but it could be rinsed with a hose before installing or allow a rain event to wash out before pulling samples.

Filter Socks should be inspected regularly to ensure that they are intact and the area behind the Filter Socks is not heavy with sediment.



If there is excessive ponding behind the Filter Socks, the build up should be cleaned off the sock material. Build up on the Filter Socks material can be either washed or brushed off if dry. Do Not use high pressure pressure washer to wash Filter Socks.



Filter Socks are easy to repair if they get a hole. Simply pigtail the hole and use a cable tie/zip-tie to seal the hole.

Stormwater **BIOCHAR** LLC

PHONE

(503) 789-6760

EMAIL

info@
Stormwater
BIOCHAR.COM

Simple • Proven • Effective

Stormwater **BIOCHAR**.COM
Biochar for stormwater treatment since 2010

THE RIGHT **BIOCHAR**,
THE RIGHT **BLEND**, DIALED IN.TM